

OVERPACK

1. Please print document at 100% or 'Actual Size' to ensure height of lettering is at least 12mm.
2. Cut out the wording 'OVERPACK' and add to your returns bag, ensuring it does not cover the UN3373 diamond on the bag. You can add to the front or back of the bag.
3. Place your sample in a rigid cardboard box and add into returns bag for shipping.
4. Add your returns label to the returns bag, again ensuring it does not cover the UN3373 diamond or the OVERPACK wording. You can add to front or back of the bag.